




Quick Start Guide

Orb 2



Know Your Orb 2



LED Indicator Status:

Flashing Green: Hotspot Enabled


Flashing Red: Wi-Fi disconnected

Solid Green: Booting Up/ Online


Solid Red: Undergoing Reset

Installation


Mounting Options




Step 1 Mark the Mounting Holes. Use the included template to mark the screw holes and drill them. Install Wall Anchor if installing on stucco, brick, or concrete. For wood, drywall or soft surface, skip this step.




Step 2 Install the Mounting Plate. Using a Phillips-head screwdriver and the included screws, install the plate as shown below (ceiling or wall mounted).



Step 3 Install the Camera Body to the Mount. Twist the camera onto the Mounting Plate. Afterwards, connect the included power supply and (if not using WiFi), connect an ethernet cable. See below. Note that the Camera does not support PoE.



Step 4 (Optional) Install the SD Card. Locate the SD card slot behind the camera body. The Reset button will be located there as well.



Package Contents




Using IC View Pro

1 Power on the Orb 2 camera and download the **IC View Pro App** from Google Play or the Apple App Store.




2 Open the App, and register a new account if you do not already have one.



3 On the device page of the app press the "+" icon to initiate QR code scanning.

4 Scan the QR code on the bottom of the bottom of the Orb 2. You can also manually enter the serial number on the following page.




5 Tap "Next" if you see a flashing green light on the Orb 2's LED Indicator, which means the hotspot is active (If not, press the reset button on the back of the device).

6 Connect your mobile device to the Orb 2's hotspot. The Wi-Fi name will appear as the *Orb2-device serial number*.

7 Choose a password for your Orb 2, then follow the in-app instructions.




8 Login to the local Wi-Fi network. Then, create a device name and set the time zone.




Privacy Mode

The Orb 2 includes a convenient Privacy Mode that hides the camera lens and instantly stops live audio and video and recording, giving you complete control and peace of mind whenever you need privacy.

To quickly enable Privacy Mode, tap on the  icon on the IC View Pro App.



You can also go to **Device Details > Private Plan**. You can set up time periods when Privacy Mode will be enabled.



Frequently Asked Questions

Does the Orb 2 support 5GHz Wi-Fi?

No. It works only with 2.4GHz Wi-Fi networks.

Why isn't the video camera turning on?

- Make sure the camera is using the supplied power supply and that it is connected properly.
- This camera does not support PoE power so it will need a power supply even if plugged into a PoE source.

How do I reset the Orb 2?

Locate the Reset button on the back of the lens body. While powered, press and hold the **RESET** button. Release it when you hear the audio prompt/chime. After a minute, a slow green light will show the camera is ready to set up.

Why can't I connect the camera to Wi-Fi?

Wait for the camera to flash a slow green light. Then go to your phone's Settings > Wi-Fi and connect to the "Orb2_xxx" hotspot.

Why is the camera offline?

Check if the LED is solid green.

- If **yes**, check if your Wi-Fi router is online.
- If **no**, factory reset the camera and reconnect. Make sure the Wi-Fi signal is strong.

Why can't I connect to the device hotspot?

Make sure the IC View Pro app has Location and Wi-Fi permissions.

If your phone doesn't connect automatically, go to Wi-Fi settings and connect to the hotspot manually. Stay connected to the hotspot during setup.